

arcform

ARC Wall Light – Installation Instructions

Installation MUST be carried out in accordance and compliance with current building regulations. If you are in any doubt consult a suitably qualified electrician on the correct installation of the light. Install in accordance with current IEE wiring regulations. It is recommended that this fitting is installed by a qualified electrician.

INSTALLATION NOTES

1. **Ensure that the electrical supply is OFF. Disconnect the electrical supply at the fuse-board.**
2. Attach bracket to wall adjacent to the power supply, ensure the fixings are secure and are capable of supporting the weight of the light (see below).
3. Connect the wiring, whilst supporting the weight of the light.
4. Attach the wall rose to the bracket, using the 2 thumb screws through the sides of the wall bracket, ensuring all wires are pushed inside.
5. Fit bulb – do not fit a bulb of greater wattage than recommended.

CLEANING & MAINTENANCE

Metal finishes should only be cleaned with a soft, dry cloth. Do not use polishes or abrasives. Switch off power to the fitting before cleaning.

Please note that over time the brass/copper finish may develop a slight patina over time due to the natural properties of the material.

PACKAGING

We try to be responsible with our packaging, as well as ensuring your light arrives in perfect condition.

Cardboard boxes	Recyclable
Cotton bags	Re-usable
Packing chips	Compostable
Bubble wrap	Non-recyclable

SPECIFICATIONS

Bulb type	B22 LED
Maximum bulb rating	7w LED maximum 40w incandescent
Suitability	Indoor use only
IP Rating	IP20

Height	300mm
Width	130mm
Projection from wall	150mm
Weight	2.0 kg approx.